



JAGUAR®

VERSION: 2012.05 DATE: MAY, 2012

MODELS LIST:

| | | |
|------------------------|-------------|----------------------------|
| S-TYPE | 2000 ~ 2001 | |
| | 2002 ~ 2003 | 2.5L Normally aspirated V6 |
| | | 3.0L normally aspirated V6 |
| | | 4.2L normally aspirated V8 |
| | | 4.2L supercharged V8 |
| | 2004 ~ 2006 | 2.5L normally aspirated V6 |
| | | 3.0L normally aspirated V6 |
| | | 4.2L super charge V8 |
| | 2006 ~ 2008 | 2.5L normally aspirated V6 |
| | | 3.0L normally aspirated V6 |
| | | 4.2L normally aspirated V8 |
| | | 4.2L supercharge V8 |
| Diesel fuel capability | | |
| MODEL X-TYPE | 2001 | 2.0L AJ61 |
| | 2001 | 2.5L AJ61 |
| | 2001 | 3.0L AJ61 |
| | 2003 | 2.0L AJ61 |
| | 2003 | 2.5L AJ61 |
| | 2003 | 3.0L AJ61 |
| | 2004 - 2008 | 2.0L AJ61 |
| | 2004 - 2008 | 2.5L AJ61 |
| | 2004 - 2008 | 3.0L AJ61 |
| | 2004 - 2008 | 2.0L Duratorq TDCi |
| | 2004 - 2008 | 2.2L Duratorq TDCi |
| | 2008 | 2.0L AJ61 |
| | 2008 | 2.5L AJ61 |

| | | |
|-----------------|----------------|----------------------------|
| | 2008 | 3.0L AJ61 |
| | 2008 | 2.0L Duratorq TDCi |
| | 2008 | 2.2L Duratorq TDCi |
| | 2009 | 2.0L AJ61 |
| | 2009 | 2.5L AJ61 |
| | 2009 | 3.0L AJ61 |
| | 2009 | 2.0L Duratorq TDCi |
| | 2009 | 2.2L Duratorq TDCi |
| MODEL XJ-Series | 1998 | 1998 4.0L |
| | 2002.5 | 3.0L Normally aspirated V6 |
| | 2002.5 | 3.5L Normally aspirated V8 |
| | 2002.5 | 4.2L Normally aspirated V8 |
| | 2002.5 | 4.2L Supercharged V8 |
| | 2005 | 3.0L Normally aspirated V6 |
| | 2005 | 3.5L Normally aspirated V8 |
| | 2005 | 4.2L Normally aspirated V8 |
| | 2005 | 4.2L Supercharged V8 |
| | 2006 | 3.0L Normally aspirated V6 |
| | 2006 | 3.5L Normally aspirated V8 |
| | 2006 | 4.2L Normally aspirated V8 |
| | 2006 | 4.2L Supercharged V8 |
| | 2006 | 2.7L Diesel V6 |
| | 2008 - 2009 | 3.0L Normally aspirated V6 |
| | 2008 - 2009 | 3.5L Normally aspirated V8 |
| | 2008 - 2009 | 4.2L Supercharged V8 |
| | 2008 - 2009 | Diesel V6 |
| | 2010 - 2011 | 3.0L Normally aspirated V6 |
| | MODEL XJ8-TYPE | 2000 |
| | 2001~2002 | 3.2L |
| MODEL XKR-TYPE | 2003 | 4.2L Normally aspirated V8 |
| MODEL XKR-TYPE | 2003 | 4.2L Supercharged V8 |
| | 2006 ~ 2009 | Normally aspirated V8 3.5L |
| | 2006 ~ 2009 | Normally aspirated V8 4.2L |

| | | |
|---------------|-------------|--------------------------|
| MODEL XF-TYPE | 2006 ~ 2009 | Supercharged V8 |
| | 2010 ~ 2011 | Normally aspirated V8 |
| | 2010 ~ 2011 | Supercharged V8 |
| | 2008 | Normally aspired V6 |
| | | Supercharged V8 |
| | | Diesel V6 |
| | 2010 - 2011 | Normally aspired V8 4.2L |

Models equipped with OBD-II Connector, SELECT BY MODEL:

S-TYPE

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING | Activation |
|--------|---------|-------------------------------------|-----------------|------------------|-------------|--------|------------|
| S-TYPE | 00 – 01 | ENGINE | ✓ | ✓ | ✓ | | |
| | | AT | ✓ | ✓ | ✓ | | |
| | | ABS | ✓ | ✓ | ✓ | | |
| | | SRS | ✓ | ✓ | ✓ | | |
| | | GEM (Generic Electric Module) | ✓ | ✓ | ✓ | | |
| | | DDM (Drivers Door Module) | ✓ | ✓ | ✓ | | |
| | | DSM (Driver Seat Module) | ✓ | ✓ | ✓ | | |
| | | REM (Rear Electric Module) | ✓ | ✓ | ✓ | | |
| | | CCM (Climate Control System) | ✓ | ✓ | ✓ | | |
| | | ACM (Audio Control Module) | ✓ | ✓ | ✓ | | |
| | | ICM (Instrument Pack System) | ✓ | ✓ | ✓ | | |
| | | MCM (Message Center Control Module) | ✓ | ✓ | ✓ | | |
| | | PAM (Parking aid control module) | ✓ | ✓ | ✓ | | |
| | | Suspension | ✓ | ✓ | ✓ | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING | Activation |
|---|-------------|------------------------------------|-----------------|------------------|-------------|--------|------------|
| S-TYPE 2.5L Normally aspirated V6 | 2002 ~ 2003 | ENGINE | ✓ | ✓ | ✓ | | ✓ |
| | | AT | ✓ | ✓ | ✓ | | |
| | | ABS | ✓ | ✓ | ✓ | | ✓ |
| | | RCM/SRS | ✓ | ✓ | ✓ | | |
| | | ICM (Instrument Pack System) | ✓ | ✓ | ✓ | | ✓ |
| | | Climate control module | ✓ | ✓ | ✓ | | |
| | | General electronics control | ✓ | ✓ | | | |
| | | Driver's door module | ✓ | ✓ | | | |
| | | Driver seat module | ✓ | ✓ | | | |
| | | Rear electronic control module | ✓ | ✓ | | | |
| | | ACM (Audio control module) | ✓ | ✓ | | | |
| | | Electronic parking brake | ✓ | ✓ | | | |
| | | Intrusion sensor | ✓ | ✓ | | | |
| | | Steering column lock module | ✓ | ✓ | | | |
| | | | | | | | |
| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING | Activation |
| S-TYPE 3.0L normally aspirated V6 | 2002 ~ 2003 | ENGINE | ✓ | ✓ | ✓ | | |
| | | AT | ✓ | ✓ | ✓ | | |
| | | ABS | ✓ | ✓ | ✓ | | |
| | | RCM/SRS | ✓ | ✓ | ✓ | | |
| | | ICM (Instrument pack system) | ✓ | ✓ | ✓ | | |
| | | Climate control module | ✓ | ✓ | ✓ | | |
| | | General electronics control module | ✓ | ✓ | | | |
| | | Driver's door module | ✓ | ✓ | | | |
| | | Driver seat module | ✓ | ✓ | | | |
| | | Rear electronic control module | ✓ | ✓ | | | |
| | | ACM (Audio control module) | ✓ | ✓ | | | |
| | | Electronic parking brake | ✓ | ✓ | | | |
| | | Navigation control module | ✓ | ✓ | | | |
| | | Headlamp levelling system | ✓ | ✓ | | | |
| PAM (Parking aid control module) | ✓ | ✓ | | | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING | Activation |
|-----------------------------------|------------|------------------------------------|-----------------|------------------|-------------|--------|------------|
| S-TYPE 4.2L normally aspirated V8 | 2002 ~2003 | ENGINE | ✓ | ✓ | ✓ | | |
| | | AT | ✓ | ✓ | ✓ | | |
| | | ABS | ✓ | ✓ | ✓ | | |
| | | RCM/SRS | ✓ | ✓ | ✓ | | |
| | | ICM (Instrument pack system) | ✓ | ✓ | ✓ | | |
| | | Climate control module | ✓ | ✓ | ✓ | | |
| | | General electronics control module | ✓ | ✓ | | | |
| | | Driver's door module | ✓ | ✓ | | | |
| | | Driver's seat module | ✓ | ✓ | | | |
| | | Rear electronic control module | ✓ | ✓ | | | |
| | | ACM (Audio control module) | ✓ | ✓ | | | |
| | | Electronic parking brake | ✓ | ✓ | | | |
| | | Intrusion sensor module | ✓ | ✓ | | | |
| | | Steering column lock module | ✓ | ✓ | | | |
| | | PAM (Parking aid control module) | ✓ | ✓ | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING | Activation |
|-----------------------------------|----------------|------------------------------------|-----------------|------------------|-------------|--------|------------|
| S-TYPE 4.2L supercharged V8 | 2002 ~ 2003 | ENGINE | ✓ | v | ✓ | | |
| | | AT | ✓ | v | ✓ | | |
| | | ABS | ✓ | ✓ | ✓ | | |
| | | RCM/SRS | ✓ | ✓ | ✓ | | |
| | | ICM (Instrument pack system) | ✓ | ✓ | ✓ | | |
| | | Climate control module | ✓ | ✓ | ✓ | | |
| | | General electronics control module | ✓ | ✓ | | | |
| | | Driver's door module | ✓ | ✓ | | | |
| | | Driver's seat module | ✓ | ✓ | | | |
| | | Rear electronic control module | ✓ | ✓ | | | |
| | | ACM (Audio control module) | ✓ | ✓ | | | |
| | | Electronic parking brake | ✓ | ✓ | | | |
| | | Intrusion sensor module | ✓ | ✓ | | | |
| | | Steering column lock module | ✓ | ✓ | | | |
| | | Navigation control module | ✓ | ✓ | | | |
| | | Headlamp levelling system | ✓ | ✓ | | | |
| Adaptive damping ride control | ✓ | v | | | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING | Activation |
|---|---------------|------------------------------------|-----------------|------------------|-------------|--------|------------|
| S-TYPE 2.5L normally aspirated V6 | 2004 ~2006 | ENGINE | ✓ | ✓ | ✓ | | ✓ |
| | | AT | ✓ | ✓ | ✓ | | |
| | | ABS | ✓ | ✓ | ✓ | | ✓ |
| | | RCM/SRS | ✓ | ✓ | ✓ | | |
| | | ICM (Instrument pack system) | ✓ | ✓ | ✓ | | |
| | | Climate control module | ✓ | ✓ | ✓ | | |
| | | Parking brake control module | ✓ | ✓ | | | |
| | | General electronics control module | ✓ | ✓ | | | |
| | | Intrusion sensor module | ✓ | ✓ | | | |
| | | Headlamp levelling system | ✓ | ✓ | | | |
| | | ACM (Audio control module) | ✓ | ✓ | | | |
| | | Driver's door module | ✓ | ✓ | | | |
| | | Rear electronic control module | ✓ | ✓ | | | |
| | | Steering column lock module | ✓ | ✓ | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING | Activation | |
|---|---------------|-------------------------------------|-----------------|------------------|-------------|--------|------------|---|
| S-TYPE 3.0L normally aspirated V6 | 2004 ~2006 | ENGINE | ✓ | ✓ | ✓ | | ✓ | |
| | | AT | ✓ | ✓ | ✓ | | | |
| | | ABS | ✓ | ✓ | ✓ | | ✓ | |
| | | SRS | ✓ | ✓ | ✓ | | | |
| | | GEM (Generic Electric Module) | ✓ | ✓ | ✓ | | | |
| | | DDM (Drivers Door Module) | ✓ | ✓ | ✓ | | | |
| | | DSM (Driver Seat Module) | ✓ | ✓ | ✓ | | | |
| | | REM (Rear Electric Module) | ✓ | ✓ | ✓ | | | |
| | | ACM (Audio Control Module) | ✓ | ✓ | ✓ | | | |
| | | SSM (Adaptive Damping Ride Control) | ✓ | ✓ | ✓ | | | |
| | | HLM (Headlamp Leveling System) | ✓ | ✓ | ✓ | | | |
| | | Instrument cluster control module | ✓ | ✓ | ✓ | | | ✓ |
| | | Climate control module | ✓ | ✓ | ✓ | | | ✓ |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING | Activation |
|---|----------------|------------------------------------|-----------------|------------------|-------------|--------|------------|
| S-TYPE 4.2L normally aspirated V8 | 2004 ~ 2006 | ENGINE | ✓ | ✓ | ✓ | | |
| | | AT | ✓ | ✓ | ✓ | | |
| | | ABS | ✓ | ✓ | ✓ | | |
| | | RCM/SRS | ✓ | ✓ | ✓ | | |
| | | ICM (Instrument pack system) | ✓ | ✓ | ✓ | | |
| | | Climate control module | ✓ | ✓ | ✓ | | |
| | | Parking brake control module | ✓ | ✓ | | | |
| | | General electronics control module | ✓ | ✓ | | | |
| | | Intrusion sensor module | ✓ | ✓ | | | |
| | | Driver's door module | ✓ | ✓ | | | |
| | | Driver's seat module | ✓ | ✓ | | | |
| | | Rear electronic control module | ✓ | ✓ | | | |
| | | PAM(Parking aid control module) | ✓ | ✓ | | | |
| | | ACM (Audio control module) | ✓ | ✓ | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING | Activation |
|----------------------------------|----------------|------------------------------------|-----------------|------------------|-------------|--------|------------|
| S-TYPE 4.2L supercharge V8 | 2004 ~ 2006 | ENGINE | ✓ | ✓ | ✓ | | |
| | | AT | ✓ | ✓ | ✓ | | |
| | | ABS | ✓ | ✓ | ✓ | | |
| | | RCM/SRS | ✓ | ✓ | ✓ | | |
| | | ICM (Instrument pack system) | ✓ | ✓ | ✓ | | |
| | | Climate control module | ✓ | ✓ | ✓ | | |
| | | Parking brake control module | ✓ | ✓ | | | |
| | | General electronics control module | ✓ | ✓ | | | |
| | | Intrusion sensor module | ✓ | ✓ | | | |
| | | Driver's seat module | ✓ | ✓ | | | |
| | | Rear electronic control module | ✓ | ✓ | | | |
| | | PAM (Parking aid control module) | ✓ | ✓ | | | |
| | | ACM (Audio control module) | ✓ | ✓ | | | |
| | | Headlamp levelling system | ✓ | ✓ | | | |
| | | Navigation control module | ✓ | ✓ | | | |
| | | Adaptive damping ride control | ✓ | ✓ | | | |
| Steering column lock module | ✓ | ✓ | | | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING | Activation |
|-------------------------------------|----------------|------------------------------------|-----------------|------------------|-------------|--------|------------|
| S-TYPE Diesel fuel capability | 2004 ~ 2006 | ENGINE | ✓ | ✓ | ✓ | | |
| | | AT | ✓ | ✓ | ✓ | | |
| | | ABS | ✓ | ✓ | ✓ | | |
| | | ICM (Instrument Pack System) | ✓ | ✓ | ✓ | | |
| | | AC | ✓ | ✓ | ✓ | | |
| | | RCM/SRS | ✓ | ✓ | ✓ | | |
| | | Parking brake control module | ✓ | ✓ | | | |
| | | General electronics control module | ✓ | ✓ | | | |
| | | Intrusion sensor module | ✓ | ✓ | | | |
| | | Driver's door module | ✓ | ✓ | | | |
| | | Driver's seat module | ✓ | ✓ | | | |
| | | Rear electronic control module | ✓ | ✓ | | | |
| | | PAM (Parking aid control module) | ✓ | ✓ | | | |
| | | ACM(Audio control module) | ✓ | ✓ | | | |
| | | Headlamp levelling system | ✓ | ✓ | | | |
| | | Navigation control module | ✓ | ✓ | | | |
| | | Steering column lock module | ✓ | ✓ | | | |
| Auxiliary heater control module | ✓ | ✓ | | | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING | Activation |
|---|----------------|------------------------------------|-----------------|------------------|-------------|--------|------------|
| S-TYPE 2.5L normally aspirated V6 | 2006 ~ 2008 | ENGINE | ✓ | ✓ | ✓ | | |
| | | AT | ✓ | ✓ | ✓ | | |
| | | ABS | ✓ | ✓ | ✓ | | |
| | | ICM (Instrument pack system) | ✓ | ✓ | ✓ | | |
| | | AC | ✓ | ✓ | ✓ | | |
| | | Parking brake control module | ✓ | ✓ | | | |
| | | RCM/SRS | ✓ | ✓ | ✓ | | |
| | | Intrusion sensor module | ✓ | ✓ | | | |
| | | PAM (Parking aid control module) | ✓ | ✓ | | | |
| | | ACM (Audio control module) | ✓ | ✓ | | | |
| | | Driver's door module | ✓ | ✓ | | | |
| | | General electronics control module | ✓ | ✓ | | | |
| | | Rear electronic control module | ✓ | ✓ | | | |
| | | Tire pressure monitor module | ✓ | ✓ | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING | Activation |
|---|----------------|------------------------------------|-----------------|------------------|-------------|--------|------------|
| S-TYPE 3.0L normally aspirated V6 | 2006 ~ 2008 | ENGINE | ✓ | ✓ | ✓ | | |
| | | AT | ✓ | ✓ | ✓ | | |
| | | ABS | ✓ | ✓ | ✓ | | |
| | | ICM(Instrument pack system) | ✓ | ✓ | ✓ | | |
| | | AC | ✓ | ✓ | ✓ | | |
| | | Parking brake control module | ✓ | ✓ | | | |
| | | RCM/SRS | ✓ | ✓ | ✓ | | |
| | | Intrusion sensor module | ✓ | ✓ | | | |
| | | PAM(Parking aid control module) | ✓ | ✓ | | | |
| | | ACM(Audio control module) | ✓ | ✓ | | | |
| | | Driver's door module | ✓ | ✓ | | | |
| | | Driver's seat module | ✓ | ✓ | | | |
| | | General electronics control module | ✓ | ✓ | | | |
| | | Rear electronic control module | ✓ | ✓ | | | |
| Navigation control module | ✓ | ✓ | | | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING | Activation |
|---|----------------|------------------------------------|-----------------|------------------|-------------|--------|------------|
| S-TYPE 4.2L normally aspirated V8 | 2006 ~ 2008 | ENGINE | ✓ | ✓ | ✓ | | |
| | | AT | ✓ | ✓ | ✓ | | |
| | | ABS | ✓ | ✓ | ✓ | | |
| | | ICM(Instrument pack system) | ✓ | ✓ | ✓ | | |
| | | AC | ✓ | ✓ | ✓ | | |
| | | Parking brake control module | ✓ | ✓ | | | |
| | | RCM/SRS | ✓ | ✓ | ✓ | | |
| | | Intrusion sensor module | ✓ | ✓ | | | |
| | | PAM(Parking aid control module) | ✓ | ✓ | | | |
| | | ACM(Audio control module) | ✓ | ✓ | | | |
| | | Driver's seat module | ✓ | ✓ | | | |
| | | General electronics control mdoule | ✓ | ✓ | | | |
| | | Rear electronic control module | ✓ | ✓ | | | |
| | | Navigation control module | ✓ | ✓ | | | |
| | | Tire pressure monitor module | ✓ | ✓ | | | |
| Steering column lock module | ✓ | ✓ | | | | | |
| Headlamp levelling system | ✓ | ✓ | | | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING | Activation |
|----------------------------------|----------------|------------------------------------|-----------------|------------------|-------------|--------|------------|
| S-TYPE 4.2L supercharge V8 | 2006 ~ 2008 | ENGINE | ✓ | ✓ | ✓ | | |
| | | AT | ✓ | ✓ | ✓ | | |
| | | ABS | ✓ | ✓ | ✓ | | |
| | | ICM(Instrument pack system) | ✓ | ✓ | ✓ | | |
| | | AC | ✓ | ✓ | ✓ | | |
| | | Parking brake control module | ✓ | ✓ | | | |
| | | RCM/SRS | ✓ | ✓ | ✓ | | |
| | | Intrusion sensor module | ✓ | ✓ | | | |
| | | PAM(Parking aid control module) | ✓ | ✓ | | | |
| | | ACM(Audio control module) | ✓ | ✓ | | | |
| | | Driver's door module | ✓ | ✓ | | | |
| | | Driver's seat module | ✓ | ✓ | | | |
| | | General electronics control module | ✓ | ✓ | | | |
| | | Rear electronic control module | ✓ | ✓ | | | |
| | | Navigation control module | ✓ | ✓ | | | |
| | | Tire pressure monitor module | ✓ | ✓ | | | |
| | | Adaptive damping ride control | ✓ | ✓ | | | |
| Headlamp levelling system | ✓ | ✓ | | | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING | Activation |
|-------------------------------------|----------------|------------------------------------|-----------------|------------------|-------------|--------|------------|
| S-TYPE Diesel fuel capability | 2006 ~ 2008 | ENGINE | ✓ | ✓ | ✓ | | |
| | | AT | ✓ | ✓ | ✓ | | |
| | | ABS | ✓ | ✓ | ✓ | | |
| | | ICM(Instrument pack system) | ✓ | ✓ | ✓ | | |
| | | AC | ✓ | ✓ | ✓ | | |
| | | Parking brake control module | ✓ | ✓ | | | |
| | | RCM/SRS | ✓ | ✓ | ✓ | | |
| | | Intrusion sensor module | ✓ | ✓ | | | |
| | | PAM(Parking aid control module) | ✓ | ✓ | | | |
| | | ACM(Audio control module) | ✓ | ✓ | | | |
| | | Driver's door module | ✓ | ✓ | | | |
| | | Driver's seat module | ✓ | ✓ | | | |
| | | General electronics control module | ✓ | ✓ | | | |
| | | Rear electronic control module | ✓ | ✓ | | | |
| | | Navigation control module | ✓ | ✓ | | | |
| | | Tire pressure monitor module | ✓ | ✓ | | | |
| | | Steering column lock module | ✓ | ✓ | | | |
| Headlamp levelling system | ✓ | ✓ | | | | | |
| Auxiliary heater control module | ✓ | ✓ | | | | | |

X-TYPE

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING | Activation |
|---------------------|------|---------------------------------|-----------------|------------------|-------------|--------|------------|
| X-TYPE 2.0L AJ61 | 2001 | ENGINE | ✓ | ✓ | ✓ | | |
| | | AT | ✓ | ✓ | ✓ | | |
| | | ABS | ✓ | ✓ | ✓ | | |
| | | SRS | ✓ | ✓ | ✓ | | |
| | | GEM (Generic Electric Module) | ✓ | ✓ | | | |
| | | ACM (Audio Control Module) | ✓ | ✓ | | | |
| | | ICM (Instrument Pack System) | ✓ | ✓ | ✓ | | |
| | | Climate control module | ✓ | ✓ | ✓ | | |
| | | Headlamp levelling system | ✓ | ✓ | | | |
| | | PAM(Parking aid control module) | ✓ | ✓ | | | |
| | | Intrusion sensor module | ✓ | ✓ | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING | Activation |
|---------------------|------|-------------------------------|-----------------|------------------|-------------|--------|------------|
| X-TYPE 2.5L AJ61 | 2001 | ENGINE | ✓ | ✓ | ✓ | | |
| | | ABS | ✓ | ✓ | ✓ | | |
| | | SRS | ✓ | ✓ | ✓ | | |
| | | GEM (Generic Electric Module) | ✓ | ✓ | | | |
| | | ACM (Audio Control Module) | ✓ | ✓ | | | |
| | | ICM (Instrument Pack System) | ✓ | ✓ | ✓ | | |
| | | Climate control module | ✓ | ✓ | ✓ | | |
| | | Navigation control module | ✓ | ✓ | | | |
| | | Intrusion sensor module | ✓ | ✓ | | | |
| | | AT | ✓ | ✓ | ✓ | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING | Activation |
|---------------------|------|-----------------------------------|-----------------|------------------|-------------|--------|------------|
| X-TYPE 3.0L AJ61 | 2001 | ENGINE | ✓ | ✓ | ✓ | | |
| | | ABS | ✓ | ✓ | ✓ | | |
| | | RCM/SRS(Restraint control module) | ✓ | ✓ | ✓ | | |
| | | ICM(Instrument pack system) | ✓ | ✓ | ✓ | | |
| | | GEM (Generic elec. module) | ✓ | ✓ | | | |
| | | ACM (Audio control module) | ✓ | ✓ | | | |
| | | Climate control module | ✓ | ✓ | ✓ | | |
| | | Navigation control module | ✓ | ✓ | | | |
| | | Intrusion sensor module | ✓ | ✓ | | | |
| | | PAM(Parking aid control module) | ✓ | ✓ | | | |
| AT | ✓ | ✓ | ✓ | | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING | Activation |
|---------------------|------|-----------------------------------|-----------------|------------------|-------------|--------|------------|
| X-TYPE 2.0L AJ61 | 2003 | ENGINE | ✓ | ✓ | ✓ | | |
| | | AT | ✓ | ✓ | ✓ | | |
| | | ABS | ✓ | ✓ | ✓ | | |
| | | RCM/SRS(Restraint control module) | ✓ | ✓ | ✓ | | |
| | | ICM(Instrument pack system) | ✓ | ✓ | ✓ | | |
| | | GEM (Generic elec. module) | ✓ | ✓ | | | |
| | | ACM (Audio control module) | ✓ | ✓ | | | |
| | | Climate contrl module | ✓ | ✓ | ✓ | | |
| | | Intrusion sensor module | ✓ | ✓ | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING | Activation |
|---------------------|------|---------------------------------|-----------------|------------------|-------------|--------|------------|
| X-TYPE 2.5L AJ61 | 2003 | ENGINE | ✓ | ✓ | ✓ | | |
| | | AT | ✓ | ✓ | ✓ | | |
| | | ABS | ✓ | ✓ | ✓ | | |
| | | SRS | ✓ | ✓ | ✓ | | |
| | | GEM (Generic Electric Module) | ✓ | ✓ | ✓ | | |
| | | ACM (Audio Control Module) | ✓ | ✓ | ✓ | | |
| | | ICM (Instrument Pack System) | ✓ | ✓ | ✓ | | ✓ |
| | | Climate control module | ✓ | ✓ | ✓ | ✓ | |
| | | Headlamp levelling system | ✓ | ✓ | ✓ | | |
| | | PAM(Parking aid control module) | ✓ | ✓ | ✓ | | |
| | | Intrusion sensor module | ✓ | ✓ | ✓ | | |
| | | Navigation control module | ✓ | ✓ | ✓ | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING | Activation |
|---------------------|------|---------------------------------|-----------------|------------------|-------------|--------|------------|
| X-TYPE 3.0L AJ61 | 2003 | ENGINE | ✓ | ✓ | ✓ | | |
| | | AT | ✓ | ✓ | ✓ | | |
| | | ABS | ✓ | ✓ | ✓ | | |
| | | SRS | ✓ | ✓ | ✓ | | |
| | | GEM (Generic Electric Module) | ✓ | ✓ | ✓ | | |
| | | ACM (Audio Control Module) | ✓ | ✓ | ✓ | | |
| | | ICM (Instrument Pack System) | ✓ | ✓ | ✓ | | ✓ |
| | | Climate control module | ✓ | ✓ | ✓ | ✓ | |
| | | Headlamp levelling system | ✓ | ✓ | ✓ | | |
| | | PAM(Parking aid control module) | ✓ | ✓ | ✓ | | |
| | | Intrusion sensor module | ✓ | ✓ | ✓ | | |
| | | Navigation control module | ✓ | ✓ | ✓ | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING | Activation |
|----------------------|----------------|-----------------------------------|-----------------|------------------|-------------|--------|------------|
| X-TYPE 2.0L AJ61 | 2004 - 2008 | ENGINE | ✓ | ✓ | ✓ | | |
| | | AT | ✓ | ✓ | ✓ | | |
| | | ABS | ✓ | ✓ | ✓ | | |
| | | RCM/SRS(Restraint control module) | ✓ | ✓ | ✓ | | |
| | | ICM(Instrument pack system) | ✓ | ✓ | ✓ | | |
| | | GEM (Generic elec. module) | ✓ | ✓ | | | |
| | | ACM (Audio control module) | ✓ | ✓ | | | |
| | | Climate contrl module | ✓ | ✓ | ✓ | | |
| | | PAM(Parking aid control module) | ✓ | ✓ | | | |
| | | Intrusion sensor module | ✓ | ✓ | | | |
| Driver's seat module | ✓ | ✓ | | | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING | Activation |
|---------------------|----------------|-------------------------------|-----------------|------------------|-------------|--------|------------|
| X-TYPE 2.5L AJ61 | 2004 - 2008 | ENGINE | ✓ | ✓ | ✓ | | |
| | | AT | ✓ | ✓ | ✓ | | |
| | | ABS | ✓ | ✓ | ✓ | | |
| | | SRS | ✓ | ✓ | ✓ | | |
| | | GEM (Generic Electric Module) | ✓ | ✓ | | | |
| | | ACM (Audio Control Module) | ✓ | ✓ | | | |
| | | ICM (Instrument Pack System) | ✓ | ✓ | ✓ | | |
| | | Climate control module | ✓ | ✓ | ✓ | | |
| | | Intrusion sensor module | ✓ | ✓ | | | |
| | | Driver's seat module | ✓ | ✓ | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING | Activation |
|----------------------|----------------|---------------------------------|-----------------|------------------|-------------|--------|------------|
| X-TYPE 3.0L AJ61 | 2004 – 2008 | ENGINE | ✓ | ✓ | ✓ | | |
| | | AT | ✓ | ✓ | ✓ | | |
| | | ABS | ✓ | ✓ | ✓ | | |
| | | SRS | ✓ | ✓ | ✓ | | |
| | | GEM (Generic Electric Module) | ✓ | ✓ | | | |
| | | ACM (Audio Control Module) | ✓ | ✓ | | | |
| | | ICM (Instrument Pack System) | ✓ | ✓ | ✓ | | |
| | | Climate control module | ✓ | ✓ | ✓ | | |
| | | PAM(Parking aid control module) | ✓ | ✓ | | | |
| | | Intrusion sensor module | ✓ | ✓ | | | |
| Driver's seat module | ✓ | ✓ | | | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | Activation |
|------------------------------------|----------------|---------------------------------|-----------------|------------------|-------------|------------|
| X-TYPE 2.0L Duratorq TDCi | 2004 – 2008 | ENGINE | ✓ | ✓ | ✓ | |
| | | AT | ✓ | ✓ | ✓ | |
| | | ABS | ✓ | ✓ | ✓ | |
| | | SRS | ✓ | ✓ | ✓ | |
| | | GEM (Generic Electric Module) | ✓ | ✓ | ✓ | |
| | | ACM (Audio Control Module) | ✓ | ✓ | ✓ | |
| | | ICM (Instrument Pack System) | ✓ | ✓ | ✓ | ✓ |
| | | Climate control module | ✓ | ✓ | ✓ | |
| | | PAM(Parking aid control module) | ✓ | ✓ | | |
| | | Intrusion sensor module | ✓ | ✓ | | |
| | | Driver's seat module | ✓ | ✓ | | |
| Fuel fired heater module | ✓ | ✓ | | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | Activation |
|------------------------------------|----------------|---------------------------------|-----------------|------------------|-------------|------------|
| X-TYPE 2.2L Duratorq TDCi | 2004 – 2008 | ENGINE | ✓ | ✓ | ✓ | |
| | | ABS | ✓ | ✓ | ✓ | |
| | | SRS | ✓ | ✓ | ✓ | |
| | | GEM (Generic Electric Module) | ✓ | ✓ | | |
| | | ACM (Audio Control Module) | ✓ | ✓ | | |
| | | ICM (Instrument Pack System) | ✓ | ✓ | ✓ | |
| | | Climate control module | ✓ | ✓ | ✓ | |
| | | PAM(Parking aid control module) | ✓ | ✓ | | |
| | | Intrusion sensor module | ✓ | ✓ | | |
| | | Driver's seat module | ✓ | ✓ | | |
| | | Fuel fired heater module | ✓ | ✓ | | |
| Navigation control module | ✓ | ✓ | | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING | Activation |
|---------------------|------|-----------------------------------|-----------------|------------------|-------------|--------|------------|
| X-TYPE 2.0L AJ61 | 2008 | ENGINE | ✓ | ✓ | ✓ | | |
| | | AT | ✓ | ✓ | ✓ | | |
| | | ABS | ✓ | ✓ | ✓ | | |
| | | RCM/SRS(Restraint control module) | ✓ | ✓ | ✓ | | |
| | | ICM(Instrument pack system) | ✓ | ✓ | ✓ | | |
| | | GEM (Generic elec. module) | ✓ | ✓ | | | |
| | | ACM (Audio control module) | ✓ | ✓ | | | |
| | | Climate control module | ✓ | ✓ | | ✓ | |
| | | Headlamp levelling system | ✓ | ✓ | | | |
| | | PAM(Parking aid control module) | ✓ | ✓ | | | |
| | | Intrusion sensor module | ✓ | ✓ | | | |
| | | Driver's seat module | ✓ | ✓ | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING | Activation |
|---------------------------|------|-------------------------------|-----------------|------------------|-------------|--------|------------|
| X-TYPE 2.5L AJ61 | 2008 | ENGINE | ✓ | ✓ | ✓ | | |
| | | AT | ✓ | ✓ | ✓ | | |
| | | ABS | ✓ | ✓ | ✓ | | |
| | | SRS | ✓ | ✓ | ✓ | | |
| | | GEM (Generic Electric Module) | ✓ | ✓ | | | |
| | | ACM (Audio Control Module) | ✓ | ✓ | | | |
| | | ICM (Instrument Pack System) | ✓ | ✓ | ✓ | | |
| | | Climate control module | ✓ | ✓ | ✓ | | |
| | | Intrusion sensor module | ✓ | ✓ | | | |
| | | Driver's seat module | ✓ | ✓ | | | |
| Navigation control module | ✓ | ✓ | | | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING | Activation |
|---------------------|------|-------------------------------|-----------------|------------------|-------------|--------|------------|
| X-TYPE 3.0L AJ61 | 2008 | ENGINE | ✓ | ✓ | ✓ | | |
| | | AT | ✓ | ✓ | ✓ | | |
| | | ABS | ✓ | ✓ | ✓ | | |
| | | SRS | ✓ | ✓ | ✓ | | |
| | | GEM (Generic Electric Module) | ✓ | ✓ | | | |
| | | ACM (Audio Control Module) | ✓ | ✓ | | | |
| | | ICM (Instrument Pack Svstem) | ✓ | ✓ | ✓ | | |
| | | Climate control module | ✓ | ✓ | ✓ | | |
| | | Driver's seat module | ✓ | ✓ | | | |
| | | Headlamp levelling svstem | ✓ | ✓ | | | |
| | | Intrusion sensor module | ✓ | ✓ | | | |
| | | Navigation control module | ✓ | ✓ | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | Activation |
|------------------------------------|------|-------------------------------|-----------------|------------------|-------------|------------|
| X-TYPE 2.0L Duratorq TDCi | 2008 | ENGINE | ✓ | ✓ | ✓ | |
| | | ABS | ✓ | ✓ | ✓ | |
| | | SRS | ✓ | ✓ | ✓ | |
| | | GEM (Generic Electric Module) | ✓ | ✓ | | |
| | | ACM (Audio Control Module) | ✓ | ✓ | | |
| | | ICM (Instrument Pack System) | ✓ | ✓ | ✓ | |
| | | Climate control module | ✓ | ✓ | ✓ | |
| | | Driver's seat module | ✓ | ✓ | | |
| | | Intrusion sensor module | ✓ | ✓ | | |
| Fuel fired heater module | ✓ | ✓ | | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | Activation |
|------------------------------------|------|-------------------------------|-----------------|------------------|-------------|------------|
| X-TYPE 2.2L Duratorq TDCi | 2008 | ENGINE | ✓ | ✓ | ✓ | |
| | | ABS | ✓ | ✓ | ✓ | |
| | | SRS | ✓ | ✓ | ✓ | |
| | | GEM (Generic Electric Module) | ✓ | ✓ | | |
| | | ACM (Audio Control Module) | ✓ | ✓ | | |
| | | ICM (Instrument Pack System) | ✓ | ✓ | ✓ | |
| | | Climate control module | ✓ | ✓ | ✓ | |
| | | Driver's seat module | ✓ | ✓ | | |
| | | Fuel fired heater module | ✓ | ✓ | | |
| | | Intrusion sensor module | ✓ | ✓ | | |
| | | Navigation control module | ✓ | ✓ | | |
| | | Headlamp levelling system | ✓ | ✓ | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING | Activation |
|----------------------|------|-----------------------------------|-----------------|------------------|-------------|--------|------------|
| X-TYPE 2.0L AJ61 | 2009 | ENGINE | ✓ | ✓ | ✓ | | |
| | | AT | ✓ | ✓ | ✓ | | |
| | | ABS | ✓ | ✓ | ✓ | | |
| | | RCM/SRS(Restraint control module) | ✓ | ✓ | ✓ | | |
| | | ICM(Instrument pack system) | ✓ | ✓ | ✓ | | |
| | | GEM (Generic elec. module) | ✓ | ✓ | | | |
| | | ACM (Audio control module) | ✓ | ✓ | | | |
| | | Climate control module | ✓ | ✓ | ✓ | | |
| | | PAM(Parking aid control module) | ✓ | ✓ | | | |
| | | Intrusion sensor module | ✓ | ✓ | | | |
| Driver's seat module | ✓ | ✓ | | | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING | Activation |
|---------------------|------|-------------------------------|-----------------|------------------|-------------|--------|------------|
| X-TYPE 2.5L AJ61 | 2009 | ENGINE | ✓ | ✓ | ✓ | | |
| | | ABS | ✓ | ✓ | ✓ | | |
| | | SRS | ✓ | ✓ | ✓ | | |
| | | GEM (Generic Electric Module) | ✓ | ✓ | | | |
| | | ACM (Audio Control Module) | ✓ | ✓ | | | |
| | | ICM (Instrument Pack System) | ✓ | ✓ | ✓ | | |
| | | Climate control module | ✓ | ✓ | ✓ | | |
| | | Intrusion sensor module | ✓ | ✓ | | | |
| | | Driver's seat module | ✓ | ✓ | | | |
| | | AT | ✓ | ✓ | ✓ | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING | Activation |
|---------------------|------|-------------------------------|-----------------|------------------|-------------|--------|------------|
| X-TYPE 3.0L AJ61 | 2009 | ENGINE | ✓ | ✓ | ✓ | | |
| | | AT | ✓ | ✓ | ✓ | | |
| | | ABS | ✓ | ✓ | ✓ | | |
| | | SRS | ✓ | ✓ | ✓ | | |
| | | GEM (Generic Electric Module) | ✓ | ✓ | | | |
| | | ACM (Audio Control Module) | ✓ | ✓ | | | |
| | | ICM (Instrument Pack Svstem) | ✓ | ✓ | ✓ | | |
| | | Climate control module | ✓ | ✓ | ✓ | | |
| | | Driver's seat module | ✓ | ✓ | | | |
| | | Headlamp levelling svstem | ✓ | ✓ | | | |
| | | Intrusion sensor module | ✓ | ✓ | | | |
| | | Navigation control module | ✓ | ✓ | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | Activation |
|------------------------------------|------|-------------------------------|-----------------|------------------|-------------|------------|
| X-TYPE 2.0L Duratorq TDCi | 2009 | ENGINE | ✓ | ✓ | ✓ | |
| | | ABS | ✓ | ✓ | ✓ | |
| | | SRS | ✓ | ✓ | ✓ | |
| | | GEM (Generic Electric Module) | ✓ | ✓ | | |
| | | ACM (Audio Control Module) | ✓ | ✓ | | |
| | | ICM (Instrument Pack Svstem) | ✓ | ✓ | ✓ | |
| | | Climate control module | ✓ | ✓ | ✓ | |
| | | Navigation control module | ✓ | ✓ | | |
| | | Intrusion sensor module | ✓ | ✓ | | |
| | | Fuel fired heater module | ✓ | ✓ | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | Activation |
|------------------------------------|------|-------------------------------|-----------------|------------------|-------------|------------|
| X-TYPE 2.2L Duratorq TDCi | 2009 | ENGINE | ✓ | ✓ | ✓ | |
| | | ABS | ✓ | ✓ | ✓ | |
| | | SRS | ✓ | ✓ | ✓ | |
| | | GEM (Generic Electric Module) | ✓ | ✓ | | |
| | | ACM (Audio Control Module) | ✓ | ✓ | | |
| | | ICM (Instrument Pack System) | ✓ | ✓ | ✓ | |
| | | Climate control module | ✓ | ✓ | ✓ | |
| | | Driver's seat module | ✓ | ✓ | | |
| | | Fuel fired heater module | ✓ | ✓ | | |
| | | Intrusion sensor module | ✓ | ✓ | | |

XJ-TYPE

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING |
|-----------------|------|------------------------------|-----------------|------------------|-------------|--------|
| XJ-TYPE 4.0L | 1998 | ENGINE | ✓ | ✓ | ✓ | |
| | | AT | ✓ | ✓ | ✓ | |
| | | ABS | ✓ | ✓ | ✓ | |
| | | ICM (Instrument Pack System) | ✓ | ✓ | ✓ | |
| | | Body processor module | ✓ | ✓ | ✓ | |
| | | RCM/SRS | ✓ | ✓ | | |
| | | Climate control module | ✓ | ✓ | ✓ | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING |
|--|--------|-----------------------------------|-----------------|------------------|-------------|--------|
| XJ-TYPE 3.0L Normally aspirated V6 | 2002.5 | ENGINE | ✓ | ✓ | ✓ | |
| | | AT | ✓ | ✓ | ✓ | |
| | | ABS | ✓ | ✓ | ✓ | |
| | | Climate contrl module | ✓ | ✓ | ✓ | |
| | | ICM(Instrument pack system) | ✓ | ✓ | ✓ | |
| | | Air suspension module | ✓ | ✓ | | |
| | | RCM/SRS(Restraint control modult) | ✓ | ✓ | ✓ | |
| | | Intrusion sensor module | ✓ | ✓ | | |
| | | PAM(Parking aid control module) | ✓ | ✓ | | |
| | | Left lighting control module | ✓ | ✓ | | |
| | | Right lighting control module | ✓ | ✓ | | |
| | | Driver's door module | ✓ | ✓ | | |
| | | Electronic parking brake | ✓ | ✓ | | |
| | | ACM (Audio control module) | ✓ | ✓ | | |
| | | GEM (Generic elec. module) | ✓ | ✓ | | |
| | | Navigation control module | ✓ | ✓ | | |
| | | Rear electronic control module | ✓ | ✓ | | |
| Steering column lock module | ✓ | ✓ | | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING |
|--|--------|-----------------------------------|-----------------|------------------|-------------|--------|
| XJ-TYPE 3.5L Normally aspirated V8 | 2002.5 | ENGINE | ✓ | ✓ | ✓ | |
| | | AT | ✓ | ✓ | ✓ | |
| | | ABS | ✓ | ✓ | ✓ | |
| | | Climate contrl module | ✓ | ✓ | ✓ | |
| | | ICM(Instrument pack system) | ✓ | ✓ | ✓ | |
| | | Air suspension module | ✓ | ✓ | | |
| | | RCM/SRS(Restraint control modult) | ✓ | ✓ | ✓ | |
| | | Intrusion sensor module | ✓ | ✓ | | |
| | | PAM(Parking aid control module) | ✓ | ✓ | | |
| | | Left lighting control module | ✓ | ✓ | | |
| | | Right lighting control module | ✓ | ✓ | | |
| | | Driver's door module | ✓ | ✓ | | |
| | | Electronic parking brake | ✓ | ✓ | | |
| | | ACM (Audio control module) | ✓ | ✓ | | |
| | | GEM (Generic elec. module) | ✓ | ✓ | | |
| | | Navigation control module | ✓ | ✓ | | |
| | | Rear electronic control module | ✓ | ✓ | | |
| | | Steering column lock module | ✓ | ✓ | | |
| | | Adaptive speed control module | ✓ | ✓ | | |
| | | Driver's seat module | ✓ | ✓ | | |
| Rear seat control module | ✓ | ✓ | | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING |
|--|--------|-----------------------------------|-----------------|------------------|-------------|--------|
| XJ-TYPE 4.2L Normally aspirated V8 | 2002.5 | ENGINE | ✓ | ✓ | ✓ | |
| | | AT | ✓ | ✓ | ✓ | |
| | | ABS | ✓ | ✓ | ✓ | |
| | | Climate contrl module | ✓ | ✓ | ✓ | |
| | | ICM(Instrument pack system) | ✓ | ✓ | ✓ | |
| | | Air suspension module | ✓ | ✓ | | |
| | | RCM/SRS(Restraint control modult) | ✓ | ✓ | ✓ | |
| | | Intrusion sensor module | ✓ | ✓ | | |
| | | PAM(Parking aid control module) | ✓ | ✓ | | |
| | | Left lighting control module | ✓ | ✓ | | |
| | | Right lighting control module | ✓ | ✓ | | |
| | | Driver's door module | ✓ | ✓ | | |
| | | Electronic parking brake | ✓ | ✓ | | |
| | | ACM (Audio control module) | ✓ | ✓ | | |
| | | GEM (Generic elec. module) | ✓ | ✓ | | |
| | | Navigation control module | ✓ | ✓ | | |
| | | Rear electronic control module | ✓ | ✓ | | |
| | | Steering column lock module | ✓ | ✓ | | |
| | | Adaptive speed control module | ✓ | ✓ | | |
| | | Driver's seat module | ✓ | ✓ | | |
| Rear seat control module | ✓ | ✓ | | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING |
|------------------------------------|--------|-----------------------------------|-----------------|------------------|-------------|--------|
| XJ-TYPE 4.2L Supercharged V8 | 2002.5 | ENGINE | ✓ | ✓ | ✓ | |
| | | AT | ✓ | ✓ | ✓ | |
| | | ABS | ✓ | ✓ | ✓ | |
| | | Climate contrl module | ✓ | ✓ | ✓ | |
| | | ICM(Instrument pack system) | ✓ | ✓ | ✓ | |
| | | Air suspension module | ✓ | ✓ | | |
| | | RCM/SRS(Restraint control module) | ✓ | ✓ | ✓ | |
| | | Intrusion sensor module | ✓ | ✓ | | |
| | | PAM(Parking aid control module) | ✓ | ✓ | | |
| | | Left lighting control module | ✓ | ✓ | | |
| | | Right lighting control module | ✓ | ✓ | | |
| | | Driver's door module | ✓ | ✓ | | |
| | | Electronic parking brake | ✓ | ✓ | | |
| | | ACM (Audio control module) | ✓ | ✓ | | |
| | | GEM (Generic elec. module) | ✓ | ✓ | | |
| | | Navigation control module | ✓ | ✓ | | |
| | | Rear electronic control module | ✓ | ✓ | | |
| Driver's seat module | ✓ | ✓ | | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING |
|--|------|-----------------------------------|-----------------|------------------|-------------|--------|
| XJ-TYPE 3.0L Normally aspirated V6 | 2005 | ENGINE | ✓ | ✓ | ✓ | |
| | | AT | ✓ | ✓ | ✓ | |
| | | ABS | ✓ | ✓ | ✓ | |
| | | Climate control module | ✓ | ✓ | ✓ | |
| | | ICM(Instrument pack system) | ✓ | ✓ | ✓ | |
| | | Air suspension module | ✓ | ✓ | | |
| | | RCM/SRS(Restraint control module) | ✓ | ✓ | ✓ | |
| | | Intrusion sensor module | ✓ | ✓ | | |
| | | PAM(Parking aid control module) | ✓ | ✓ | | |
| | | Left lighting control module | ✓ | ✓ | | |
| | | Right lighting control module | ✓ | ✓ | | |
| | | Driver's door module | ✓ | ✓ | | |
| | | Electronic parking brake | ✓ | ✓ | | |
| | | ACM (Audio control module) | ✓ | ✓ | | |
| | | GEM (Generic elec. module) | ✓ | ✓ | | |
| | | Steering column lock module | ✓ | ✓ | | |
| Rear electronic control module | ✓ | ✓ | | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING |
|--|------|-----------------------------------|-----------------|------------------|-------------|--------|
| XJ-TYPE 3.5L Normally aspirated V8 | 2005 | ENGINE | ✓ | ✓ | ✓ | |
| | | AT | ✓ | ✓ | ✓ | |
| | | ABS | ✓ | ✓ | ✓ | |
| | | Climate control module | ✓ | ✓ | ✓ | |
| | | ICM(Instrument pack system) | ✓ | ✓ | ✓ | |
| | | Air suspension module | ✓ | ✓ | | |
| | | RCM/SRS(Restraint control module) | ✓ | ✓ | ✓ | |
| | | Intrusion sensor module | ✓ | ✓ | | |
| | | PAM(Parking aid control module) | ✓ | ✓ | | |
| | | Left lighting control module | ✓ | ✓ | | |
| | | Right lighting control module | ✓ | ✓ | | |
| | | Driver's door module | ✓ | ✓ | | |
| | | Electronic parking brake | ✓ | ✓ | | |
| | | ACM (Audio control module) | ✓ | ✓ | | |
| | | GEM (Generic elec. module) | ✓ | ✓ | | |
| | | Steering column lock module | ✓ | ✓ | | |
| | | Rear electronic control module | ✓ | ✓ | | |
| Navigation control module | ✓ | ✓ | | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING |
|--|------|-----------------------------------|-----------------|------------------|-------------|--------|
| XJ-TYPE 4.2L Normally aspirated V8 | 2005 | ENGINE | ✓ | ✓ | ✓ | |
| | | AT | ✓ | ✓ | ✓ | |
| | | ABS | ✓ | ✓ | ✓ | |
| | | Climate control module | ✓ | ✓ | ✓ | |
| | | ICM(Instrument pack system) | ✓ | ✓ | ✓ | |
| | | Air suspension module | ✓ | ✓ | | |
| | | RCM/SRS(Restraint control module) | ✓ | ✓ | ✓ | |
| | | Intrusion sensor module | ✓ | ✓ | | |
| | | PAM(Parking aid control module) | ✓ | ✓ | | |
| | | Left lighting control module | ✓ | ✓ | | |
| | | Right lighting control module | ✓ | ✓ | | |
| | | Driver's door module | ✓ | ✓ | | |
| | | Electronic parking brake | ✓ | ✓ | | |
| | | ACM (Audio control module) | ✓ | ✓ | | |
| | | GEM (Generic elec. module) | ✓ | ✓ | | |
| | | Rear electronic control module | ✓ | ✓ | | |
| Driver's seat module | ✓ | ✓ | | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING |
|------------------------------------|------|-----------------------------------|-----------------|------------------|-------------|--------|
| XJ-TYPE 4.2L Supercharged V8 | 2005 | ENGINE | ✓ | ✓ | ✓ | |
| | | AT | ✓ | ✓ | ✓ | |
| | | ABS | ✓ | ✓ | ✓ | |
| | | Climate control module | ✓ | ✓ | ✓ | |
| | | ICM(Instrument pack system) | ✓ | ✓ | ✓ | |
| | | Adaptive speed control module | ✓ | ✓ | | |
| | | Air suspension module | ✓ | ✓ | | |
| | | Rear climate control module | ✓ | ✓ | | |
| | | RCM/SRS(Restraint control module) | ✓ | ✓ | ✓ | |
| | | Intrusion sensor module | ✓ | ✓ | | |
| | | PAM(Parking aid control module) | ✓ | ✓ | | |
| | | Left lighting control module | ✓ | ✓ | | |
| | | Right lighting control module | ✓ | ✓ | | |
| | | Driver's door module | ✓ | ✓ | | |
| | | Electronic parking brake | ✓ | ✓ | | |
| | | ACM (Audio control module) | ✓ | ✓ | | |
| | | GEM (Generic elec. module) | ✓ | ✓ | | |
| | | Navigation control module | ✓ | ✓ | | |
| | | Rear electronic control module | ✓ | ✓ | | |
| | | Driver's seat module | ✓ | ✓ | | |
| Steering column lock module | ✓ | ✓ | | | | |
| Rear seat control module | ✓ | ✓ | | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING |
|--|------|---|-----------------|------------------|-------------|--------|
| XJ-TYPE 3.0L Normally aspirated V6 | 2006 | ENGINE | ✓ | ✓ | ✓ | |
| | | AT | ✓ | ✓ | ✓ | |
| | | ABS | ✓ | ✓ | ✓ | |
| | | ICM(Instrument pack system) | ✓ | ✓ | ✓ | |
| | | Heating ventilation and air conditioning control module | ✓ | ✓ | ✓ | |
| | | Parking brake control module | ✓ | ✓ | | |
| | | Tire pressure monitor module | ✓ | ✓ | | |
| | | Intrusion sensor module | ✓ | ✓ | | |
| | | PAM(Parking aid control module) | ✓ | ✓ | | |
| | | Driver's door module | ✓ | ✓ | | |
| | | ACM (Audio control module) | ✓ | ✓ | | |
| | | GEM (Generic elec. module) | ✓ | ✓ | | |
| | | Steering column lock module | ✓ | ✓ | | |
| | | Rear electronic control module | ✓ | ✓ | | |
| | | Navigation control module | ✓ | ✓ | | |
| Driver's seat module | ✓ | ✓ | | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING |
|--|------|---------------------------------|-----------------|------------------|-------------|--------|
| XJ-TYPE 3.5L Normally aspirated V8 | 2006 | ENGINE | ✓ | ✓ | ✓ | |
| | | AT | ✓ | ✓ | ✓ | |
| | | ABS | ✓ | ✓ | ✓ | |
| | | Climate control module | ✓ | ✓ | ✓ | |
| | | ICM(Instrument pack system) | ✓ | ✓ | ✓ | |
| | | Parking brake control module | ✓ | ✓ | | |
| | | Tire pressure monitor module | ✓ | ✓ | | |
| | | Intrusion sensor module | ✓ | ✓ | | |
| | | PAM(Parking aid control module) | ✓ | ✓ | | |
| | | Driver's door module | ✓ | ✓ | | |
| | | ACM (Audio control module) | ✓ | ✓ | | |
| | | GEM (Generic elec. module) | ✓ | ✓ | | |
| | | Rear electronic control module | ✓ | ✓ | | |
| | | Navigation control module | ✓ | ✓ | | |
| | | Driver's seat module | ✓ | ✓ | | |
| | | Steering column lock module | ✓ | ✓ | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING |
|--|------|---------------------------------|-----------------|------------------|-------------|--------|
| XJ-TYPE 4.2L Normally aspirated V8 | 2006 | ENGINE | ✓ | ✓ | ✓ | |
| | | AT | ✓ | ✓ | ✓ | |
| | | ABS | ✓ | ✓ | ✓ | |
| | | Climate control module | ✓ | ✓ | ✓ | |
| | | ICM(Instrument pack system) | ✓ | ✓ | ✓ | |
| | | Parking brake control module | ✓ | ✓ | | |
| | | Tire pressure monitor module | ✓ | ✓ | | |
| | | Intrusion sensor module | ✓ | ✓ | | |
| | | PAM(Parking aid control module) | ✓ | ✓ | | |
| | | Left lighting control module | ✓ | ✓ | | |
| | | Right lighting control module | ✓ | ✓ | | |
| | | Driver's door module | ✓ | ✓ | | |
| | | ACM (Audio control module) | ✓ | ✓ | | |
| | | GEM (Generic elec. module) | ✓ | ✓ | | |
| | | Rear electronic control module | ✓ | ✓ | | |
| | | Navigation control module | ✓ | ✓ | | |
| Driver's seat module | ✓ | ✓ | | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING |
|------------------------------------|------|---------------------------------|-----------------|------------------|-------------|--------|
| XJ-TYPE 4.2L Supercharged V8 | 2006 | ENGINE | ✓ | ✓ | ✓ | |
| | | AT | ✓ | ✓ | ✓ | |
| | | ABS | ✓ | ✓ | ✓ | |
| | | Climate control module | ✓ | ✓ | ✓ | |
| | | ICM(Instrument pack system) | ✓ | ✓ | ✓ | |
| | | Parking brake control module | ✓ | ✓ | | |
| | | Tire pressure monitor module | ✓ | ✓ | | |
| | | Adaptive speed control module | ✓ | ✓ | | |
| | | Rear climate control module | ✓ | ✓ | | |
| | | Intrusion sensor module | ✓ | ✓ | | |
| | | PAM(Parking aid control module) | ✓ | ✓ | | |
| | | Driver's door module | ✓ | ✓ | | |
| | | ACM (Audio control module) | ✓ | ✓ | | |
| | | GEM (Generic elec. module) | ✓ | ✓ | | |
| | | Rear electronic control module | ✓ | ✓ | | |
| | | Navigation control module | ✓ | ✓ | | |
| Driver's seat module | ✓ | ✓ | | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING |
|------------------------------|------|---------------------------------|-----------------|------------------|-------------|--------|
| XJ-TYPE 2.7L Diesel V6 | 2006 | ENGINE | ✓ | ✓ | ✓ | |
| | | AT | ✓ | ✓ | ✓ | |
| | | ABS | ✓ | ✓ | ✓ | |
| | | ICM (Instrument Pack System) | ✓ | ✓ | ✓ | |
| | | AC | ✓ | ✓ | ✓ | |
| | | Auxiliary heater control module | ✓ | ✓ | | |
| | | Parking brake control module | ✓ | ✓ | | |
| | | Tire pressure monitor module | ✓ | ✓ | | |
| | | Intrusion sensor module | ✓ | ✓ | | |
| | | PAM(Parking aid control module) | ✓ | ✓ | | |
| | | Driver's door module | ✓ | ✓ | | |
| | | Steering column lock module | ✓ | ✓ | | |
| | | ACM (Audio control module) | ✓ | ✓ | | |
| | | GEM (Generic elec. module) | ✓ | ✓ | | |
| | | Navigation control module | ✓ | ✓ | | |
| | | Rear electronic control module | ✓ | ✓ | | |
| Driver's seat module | ✓ | ✓ | | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING |
|--|----------------|---------------------------------|-----------------|------------------|-------------|--------|
| XJ-TYPE 3.0L Normally aspirated V6 | 2008 - 2009 | ENGINE | ✓ | ✓ | ✓ | |
| | | AT | ✓ | ✓ | ✓ | |
| | | ABS | ✓ | ✓ | ✓ | |
| | | Climate control module | ✓ | ✓ | ✓ | |
| | | ICM(Instrument pack system) | ✓ | ✓ | ✓ | |
| | | Parking brake control module | ✓ | ✓ | | |
| | | Tire pressure monitor module | ✓ | ✓ | | |
| | | Driver's climate seat module | ✓ | ✓ | | |
| | | Intrusion sensor module | ✓ | ✓ | | |
| | | PAM(Parking aid control module) | ✓ | ✓ | | |
| | | Driver's door module | ✓ | ✓ | | |
| | | ACM (Audio control module) | ✓ | ✓ | | |
| | | GEM (Generic elec. module) | ✓ | ✓ | | |
| | | Navigation control module | ✓ | ✓ | | |
| | | Rear electronic control module | ✓ | ✓ | | |
| | | Driver's seat module | ✓ | ✓ | | |
| Steering column lock module | ✓ | ✓ | | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING |
|--|----------------|---------------------------------|-----------------|------------------|-------------|--------|
| XJ-TYPE 3.5L Normally aspirated V8 | 2008 - 2009 | ENGINE | ✓ | ✓ | ✓ | |
| | | AT | ✓ | ✓ | ✓ | |
| | | ABS | ✓ | ✓ | ✓ | |
| | | Climate control module | ✓ | ✓ | ✓ | |
| | | ICM(Instrument pack system) | ✓ | ✓ | ✓ | |
| | | Parking brake control module | ✓ | ✓ | | |
| | | Tire pressure monitor module | ✓ | ✓ | | |
| | | Driver's climate seat module | ✓ | ✓ | | |
| | | Rear climate control module | ✓ | ✓ | | |
| | | Intrusion sensor module | ✓ | ✓ | | |
| | | PAM(Parking aid control module) | ✓ | ✓ | | |
| | | Left lighting control module | ✓ | ✓ | | |
| | | Right lighting control module | ✓ | ✓ | | |
| | | Driver's door module | ✓ | ✓ | | |
| | | ACM (Audio control module) | ✓ | ✓ | | |
| | | GEM (Generic elec. module) | ✓ | ✓ | | |
| | | Rear electronic control module | ✓ | ✓ | | |
| | | Navigation control module | ✓ | ✓ | | |
| | | Driver's seat module | ✓ | ✓ | | |
| | | Steering column lock module | ✓ | ✓ | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING |
|------------------------------------|----------------|---------------------------------|-----------------|------------------|-------------|--------|
| XJ-TYPE 4.2L Supercharged V8 | 2008 - 2009 | ENGINE | ✓ | ✓ | ✓ | |
| | | AT | ✓ | ✓ | ✓ | |
| | | ABS | ✓ | ✓ | ✓ | |
| | | Climate control module | ✓ | ✓ | ✓ | |
| | | ICM(Instrument pack system) | ✓ | ✓ | ✓ | |
| | | Parking brake control module | ✓ | ✓ | | |
| | | Tire pressure monitor module | ✓ | ✓ | | |
| | | Driver's climate seat module | ✓ | ✓ | | |
| | | Rear climate control module | ✓ | ✓ | | |
| | | Intrusion sensor module | ✓ | ✓ | | |
| | | PAM(Parking aid control module) | ✓ | ✓ | | |
| | | Driver's door module | ✓ | ✓ | | |
| | | ACM (Audio control module) | ✓ | ✓ | | |
| | | GEM (Generic elec. module) | ✓ | ✓ | | |
| | | Rear electronic control module | ✓ | ✓ | | |
| | | Driver's seat module | ✓ | ✓ | | |
| | | Steering column lock module | ✓ | ✓ | | |
| Rear seat control module | ✓ | ✓ | | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING |
|---------------------------|----------------|---------------------------------|-----------------|------------------|-------------|--------|
| XJ-TYPE Diesel V6 | 2008 - 2009 | ENGINE | ✓ | ✓ | ✓ | |
| | | AT | ✓ | ✓ | ✓ | |
| | | ABS | ✓ | ✓ | ✓ | |
| | | ICM (Instrument Pack System) | ✓ | ✓ | ✓ | |
| | | AC | ✓ | ✓ | ✓ | |
| | | Parking brake control module | ✓ | ✓ | | |
| | | Tire pressure monitor module | ✓ | ✓ | | |
| | | Driver's climate seat module | ✓ | ✓ | | |
| | | Auxiliary heater control module | ✓ | ✓ | | |
| | | Intrusion sensor module | ✓ | ✓ | | |
| | | PAM(Parking aid control module) | ✓ | ✓ | | |
| | | Driver's door module | ✓ | ✓ | | |
| | | ACM (Audio control module) | ✓ | ✓ | | |
| | | GEM (Generic elec. module) | ✓ | ✓ | | |
| | | Rear electronic control module | ✓ | ✓ | | |
| | | Driver's seat module | ✓ | ✓ | | |
| | | Steering column lock module | ✓ | ✓ | | |
| Navigation control module | ✓ | ✓ | | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING |
|--|----------------|--|-----------------|------------------|-------------|--------|
| XJ-TYPE 3.0L Normally aspirated V6 | 2010 - 2011 | ENGINE | ✓ | ✓ | | |
| | | AT | ✓ | ✓ | | |
| | | ABS | ✓ | ✓ | | |
| | | Instrument Pack System | ✓ | ✓ | | |
| | | Parking brake control module | ✓ | ✓ | | |
| | | Speed control module | ✓ | ✓ | | |
| | | Headlamp control module | ✓ | ✓ | | |
| | | Restraints control module | ✓ | ✓ | | |
| | | Vehicle immobilizer control module | ✓ | ✓ | | |
| | | Gear shift module | ✓ | ✓ | | |
| | | Restraints occupant classification system module | ✓ | ✓ | | |
| | | Rear differential control module | ✓ | ✓ | | |
| | | Body control module | ✓ | ✓ | | |
| | | Ride level control module | ✓ | ✓ | | |
| | | Safety belt pretensioner control module B - Driver side | ✓ | ✓ | | |
| | | Safety belt pretensioner control module B - Passenger side | ✓ | ✓ | | |
| | | Adaptive damping control module | ✓ | ✓ | | |
| | | Audio amplifier module | ✓ | ✓ | | |
| | | Driver's climate seat module | ✓ | ✓ | | |
| | | Headlamp control module | ✓ | ✓ | | |
| | | Passenger's seat module | ✓ | ✓ | | |
| | | Rear climate seat module | ✓ | ✓ | | |
| | | Rear heating ventilation and air conditioning control module | ✓ | ✓ | | |
| | | Side object detection control module - left | ✓ | ✓ | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING |
|-------|------|---|-----------------|------------------|-------------|--------|
| | | Side object detection control module - right | ✓ | ✓ | | |
| | | Rear gate(trunk) module | ✓ | ✓ | | |
| | | Driver's door module | ✓ | ✓ | | |
| | | Heating ventilation and air conditioning control module | ✓ | ✓ | | |
| | | Integrated control panel | ✓ | ✓ | | |
| | | Keyless vehicle module | ✓ | ✓ | | |
| | | Parking assist control module | ✓ | ✓ | | |
| | | Passenger's door module | ✓ | ✓ | | |
| | | Driver's seat module | | | | |
| | | | ✓ | ✓ | | |

XJ8-TYPE

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING |
|------------------|------|--------|-----------------|------------------|-------------|--------|
| XJ8-TYPE 4.0L | 2000 | ENGINE | ✓ | ✓ | ✓ | |
| | | AT | ✓ | ✓ | ✓ | |
| | | ABS | ✓ | ✓ | ✓ | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING |
|------------------|----------------|------------------------------|-----------------|------------------|-------------|--------|
| XJ8-TYPE 3.2L | 2001 - 2002 | ENGINE | ✓ | ✓ | ✓ | |
| | | AT | ✓ | ✓ | ✓ | |
| | | ABS | ✓ | ✓ | ✓ | |
| | | ICM (Instrument Pack System) | ✓ | ✓ | ✓ | |
| | | Body processor module | ✓ | ✓ | ✓ | |

XKR-TYPE

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING |
|-----------------------------|------|-----------------------------------|-----------------|------------------|-------------|--------|
| XKR-TYPE Supercharged V8 | 2003 | ENGINE | ✓ | ✓ | ✓ | |
| | | AT | ✓ | ✓ | ✓ | |
| | | ABS | ✓ | ✓ | ✓ | |
| | | ICM(Instrument pack system) | ✓ | ✓ | ✓ | |
| | | Adaptive speed control module | ✓ | ✓ | | |
| | | RCM/SRS(Restraint control modult) | ✓ | ✓ | ✓ | |
| | | PAM(Parking aid control module) | ✓ | ✓ | | |
| | | Left lighting control module | ✓ | ✓ | | |
| | | Right lighting control module | ✓ | ✓ | | |
| | | Climate control system | ✓ | ✓ | ✓ | |
| | | Driver's door module | ✓ | ✓ | | |
| | | Body processor module | ✓ | ✓ | | |
| | | Passenger's door module | ✓ | ✓ | | |
| | | Secutitiv lockina module | ✓ | ✓ | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING |
|-----------------------------------|------|---------------------------------|-----------------|------------------|-------------|--------|
| XKR-TYPE Normally aspirated V8 | 2003 | ENGINE | ✓ | ✓ | ✓ | |
| | | AT | ✓ | ✓ | ✓ | |
| | | ABS | ✓ | ✓ | ✓ | |
| | | RCM/SRS | ✓ | ✓ | ✓ | |
| | | ICM(Instrument pack system) | ✓ | ✓ | ✓ | |
| | | PAM(Parking aid control module) | ✓ | ✓ | | |
| | | Driver's door module | ✓ | ✓ | | |
| | | Driver's seat module | ✓ | ✓ | | |
| | | Left lighting control module | ✓ | ✓ | | |
| | | Right lighting control module | ✓ | ✓ | | |
| | | Body processor module | ✓ | ✓ | | |
| | | Passenger's door module | ✓ | ✓ | | |
| | | Secutity locking module | ✓ | ✓ | | |
| | | Climate control system | ✓ | ✓ | ✓ | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING |
|---|-----------|---|-----------------|------------------|-------------|--------|
| XKR-TYPE Normally aspirated V8 3.5L | 2006-2009 | ENGINE | ✓ | ✓ | ✓ | |
| | | AT | ✓ | ✓ | ✓ | |
| | | ABS | ✓ | ✓ | ✓ | |
| | | Instrument Pack System | ✓ | ✓ | ✓ | |
| | | Parking brake control module | ✓ | ✓ | | |
| | | Speed control module | ✓ | ✓ | | |
| | | Headlamp control module | ✓ | ✓ | | |
| | | Impact classification system | ✓ | ✓ | | |
| | | Restraints control module | ✓ | ✓ | ✓ | |
| | | Vehicle immobilizer control module | ✓ | ✓ | | |
| | | Driver's door module | ✓ | ✓ | | |
| | | Driver's seat module | ✓ | ✓ | | |
| | | Central junction box(body control module) | ✓ | ✓ | | |
| | | Floding top control module | v | ✓ | | |
| | | Heating ventilation and air conditioning control module | ✓ | ✓ | ✓ | |
| | | Integrated control panel | ✓ | ✓ | | |
| | | Keyless vehicle module | ✓ | ✓ | | |
| | | Parking assist control module | ✓ | ✓ | | |
| | | Passenger's door module | ✓ | ✓ | | |
| | | Passenger's seat module | ✓ | ✓ | | |
| Tire pressure monitor module | ✓ | ✓ | | | | |
| Auxiliary junction box(body control module) | ✓ | ✓ | | | | |
| Infotainment control module | ✓ | ✓ | | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING |
|--|---------------|---|-----------------|------------------|-------------|--------|
| XKR- TYPE Normally aspirated V8 4.2L | 2006- 2009 | ENGINE | ✓ | ✓ | ✓ | |
| | | AT | ✓ | ✓ | ✓ | |
| | | ABS | ✓ | ✓ | ✓ | |
| | | Instrument Pack System | ✓ | ✓ | ✓ | |
| | | Parking brake control module | ✓ | ✓ | | |
| | | Speed control module | ✓ | ✓ | | |
| | | Headlamp control module | ✓ | ✓ | | |
| | | Impact classification system | ✓ | ✓ | | |
| | | Restraints control module | ✓ | ✓ | ✓ | |
| | | Vehicle immobilizer control module | ✓ | ✓ | | |
| | | Driver's door module | ✓ | ✓ | | |
| | | Driver's seat module | ✓ | ✓ | | |
| | | Central junction box(body control module) | ✓ | ✓ | | |
| | | Floding top control module | ✓ | ✓ | | |
| | | Heating ventilation and air conditioning control module | ✓ | ✓ | ✓ | |
| | | Integrated control panel | ✓ | ✓ | | |
| | | Keyless vehicle module | ✓ | ✓ | | |
| | | Parking assist control module | ✓ | ✓ | | |
| | | Passenger's door module | ✓ | ✓ | | |
| | | Passenger's seat module | ✓ | ✓ | | |
| | | Tire pressure monitor module | ✓ | ✓ | | |
| Auxiliary junction box(body control module) | ✓ | ✓ | | | | |
| Infotainment control module | ✓ | ✓ | | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING |
|---|-----------|---|-----------------|------------------|-------------|--------|
| XKR-TYPE Supercharged V8 | 2006-2009 | ENGINE | ✓ | ✓ | ✓ | |
| | | AT | ✓ | ✓ | ✓ | |
| | | ABS | ✓ | ✓ | ✓ | |
| | | Instrument Pack System | ✓ | ✓ | ✓ | |
| | | Parking brake control module | ✓ | ✓ | | |
| | | Speed control module | ✓ | ✓ | | |
| | | Headlamp control module | ✓ | ✓ | | |
| | | Impact classification system | ✓ | ✓ | | |
| | | Restraints control module | ✓ | ✓ | ✓ | |
| | | Vehicle immobilizer control module | ✓ | ✓ | | |
| | | Driver's door module | ✓ | ✓ | | |
| | | Driver's seat module | ✓ | ✓ | | |
| | | Central junction box(body control module) | ✓ | ✓ | | |
| | | Folding top control module | ✓ | ✓ | | |
| | | Heating ventilation and air conditioning control module | ✓ | ✓ | ✓ | |
| | | Integrated control panel | ✓ | ✓ | | |
| | | Keyless vehicle module | ✓ | ✓ | | |
| | | Parking assist control module | ✓ | ✓ | | |
| | | Passenger's door module | ✓ | ✓ | | |
| | | Passenger's seat module | ✓ | ✓ | | |
| | | Tire pressure monitor module | ✓ | ✓ | | |
| Auxiliary junction box(body control module) | ✓ | ✓ | | | | |
| Infotainment control module | ✓ | ✓ | | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING |
|-----------------------------------|-----------|---|-----------------|------------------|-------------|--------|
| XKR-TYPE Normally aspirated V8 | 2010-2011 | ENGINE | ✓ | ✓ | | |
| | | AT | ✓ | ✓ | | |
| | | ABS | ✓ | ✓ | | |
| | | Instrument Pack System | ✓ | ✓ | | |
| | | Parking brake control module | ✓ | ✓ | | |
| | | Speed control module | ✓ | ✓ | | |
| | | Headlamp control module | ✓ | ✓ | | |
| | | Impact classification system | ✓ | ✓ | | |
| | | Restraints control module | ✓ | ✓ | | |
| | | Vehicle immobilizer control module | ✓ | ✓ | | |
| | | Gear shift module | ✓ | ✓ | | |
| | | Restraints occupant classification system module | ✓ | ✓ | | |
| | | Rear differential control module | ✓ | ✓ | | |
| | | Driver's door module | ✓ | ✓ | | |
| | | Driver's seat module | ✓ | ✓ | | |
| | | Central junction box(body control module) | ✓ | ✓ | | |
| | | Floding top control module | ✓ | ✓ | | |
| | | Heating ventilation and air conditioning control module | ✓ | ✓ | | |
| | | Integrated control panel | ✓ | ✓ | | |
| | | Keyless vehicle module | ✓ | ✓ | | |
| | | Parking assist control module | ✓ | ✓ | | |
| Passenger's door module | ✓ | ✓ | | | | |
| Passenger's seat module | ✓ | ✓ | | | | |
| Tire pressure monitor module | ✓ | ✓ | | | | |

Specification

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING |
|-------|------|---|-----------------|------------------|-------------|--------|
| | | Auxiliary junction box(body control module) | ✓ | ✓ | | |
| | | Driver's climate seat module | ✓ | ✓ | | |
| | | Infotainment control module | ✓ | ✓ | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING |
|---|-----------|--|-----------------|------------------|-------------|--------|
| XKR-TYPE Supercharged V8 | 2010-2011 | ENGINE | ✓ | ✓ | | |
| | | AT | ✓ | ✓ | | |
| | | ABS | ✓ | ✓ | | |
| | | Instrument Pack System | ✓ | ✓ | | |
| | | Parking brake control module | ✓ | ✓ | | |
| | | Speed control module | ✓ | ✓ | | |
| | | Headlamp control module | ✓ | ✓ | | |
| | | Impact classification system | ✓ | ✓ | | |
| | | Restraints control module | ✓ | ✓ | | |
| | | Vehicle immobilizer control module | ✓ | ✓ | | |
| | | Gear shift module | ✓ | ✓ | | |
| | | Restraints occupant classification system module | ✓ | ✓ | | |
| | | Rear differential control module | ✓ | ✓ | | |
| | | Driver's door module | ✓ | ✓ | | |
| | | Driver's seat module | ✓ | ✓ | | |
| | | Central junction box(body control module) | ✓ | ✓ | | |
| | | Flooding top control module | ✓ | ✓ | | |
| Heating ventilation and air conditioning control module | ✓ | ✓ | | | | |
| Integrated control panel | ✓ | ✓ | | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING |
|-------|------|---|-----------------|------------------|-------------|--------|
| | | Keyless vehicle module | ✓ | ✓ | | |
| | | Parking assist control module | ✓ | ✓ | | |
| | | Passenger's door module | ✓ | ✓ | | |
| | | Passenger's seat module | ✓ | ✓ | | |
| | | Tire pressure monitor module | ✓ | ✓ | | |
| | | Auxiliary junction box(body control module) | ✓ | ✓ | | |
| | | Driver's climate seat module | ✓ | ✓ | | |
| | | Infotainment control module | ✓ | ✓ | | |

XF-TYPE

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING |
|-----------------------------------|------|--|-----------------|------------------|-------------|--------|
| XF-TYPE Normally aspired V6 | 2008 | ENGINE | ✓ | ✓ | | |
| | | AT | ✓ | ✓ | | |
| | | ABS | ✓ | ✓ | | |
| | | ICM (Instrument Pack System) | ✓ | ✓ | | |
| | | Parking brake control module | ✓ | ✓ | | |
| | | Gear shift module | ✓ | ✓ | | |
| | | Speed control module | ✓ | ✓ | | |
| | | Restraints control module | ✓ | ✓ | | |
| | | Restraints occupant classification system module | ✓ | ✓ | | |
| | | Headlamp control module | ✓ | ✓ | | |
| | | Impact classification system | ✓ | ✓ | | |
| | | Vehicle immobilizer control module | ✓ | ✓ | | |
| | | Central junction box | ✓ | ✓ | | |
| | | Auxiliary junction box | ✓ | ✓ | | |
| | | Driver's climate seat module | ✓ | ✓ | | |
| | | AC | ✓ | ✓ | | |
| | | Parking assist control module | ✓ | ✓ | | |
| | | Infotainment control module | ✓ | ✓ | | |
| | | Integrated control module | ✓ | ✓ | | |
| | | Driver's door module | ✓ | ✓ | | |
| Tire pressure monitor module | ✓ | ✓ | | | | |
| Driver's seat module | ✓ | ✓ | | | | |
| Keyless vehicle module | ✓ | ✓ | | | | |
| Passenger's door module | ✓ | ✓ | | | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING |
|-------|------|--|-----------------|------------------|-------------|--------|
| | | Side object detection control module - left | ✓ | ✓ | | |
| | | Side object detection control module - right | ✓ | ✓ | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING |
|-------------------------|------|-----------------------------|-----------------|------------------|-------------|--------|
| XF-TYPE Supercharged V8 | 2008 | ENGINE | ✓ | ✓ | | |
| | | AT | ✓ | ✓ | | |
| | | ABS | ✓ | ✓ | | |
| | | ICM(Instrument Pack System) | ✓ | ✓ | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING |
|-------------------|------|-----------------------------|-----------------|------------------|-------------|--------|
| XF-TYPE Diesel V6 | 2008 | ENGINE | ✓ | ✓ | | |
| | | AT | ✓ | ✓ | | |
| | | ABS | ✓ | ✓ | | |
| | | ICM(Instrument Pack System) | ✓ | ✓ | | |

| MODEL | YEAR | SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING |
|---|-------------|---|-----------------|------------------|-------------|--------|
| XF-TYPE Normally aspired V8 4.2L | 2010 - 2011 | ENGINE | ✓ | ✓ | | |
| | | AT | ✓ | ✓ | | |
| | | ABS | ✓ | ✓ | | |
| | | Instrument Pack System | ✓ | ✓ | | |
| | | Parking brake control module | ✓ | ✓ | | |
| | | Speed control module | ✓ | ✓ | | |
| | | Headlamp control module | ✓ | ✓ | | |
| | | Impact classification system | ✓ | ✓ | | |
| | | Restraints control module | ✓ | ✓ | | |
| | | Vehicle immobilizer control module | ✓ | ✓ | | |
| | | Gear shift module | ✓ | ✓ | | |
| | | Restraints occupant classification system module | ✓ | ✓ | | |
| | | Driver's door module | ✓ | ✓ | | |
| | | Driver's seat module | ✓ | ✓ | | |
| | | Central junction box(body control module) | ✓ | ✓ | | |
| | | Heating ventilation and air conditioning control module | ✓ | ✓ | | |
| | | Inteagrated control panel | ✓ | ✓ | | |
| | | Keyless vehicle module | ✓ | ✓ | | |
| | | Passenger's door module | ✓ | ✓ | | |
| | | Tire pressure monitor module | ✓ | ✓ | | |
| | | Auxiliary junction box(body control module) | ✓ | ✓ | | |
| | | Driver's climate seat module | ✓ | ✓ | | |
| | | Side object detection control module - left | ✓ | ✓ | | |
| | | Side object detection control module - right | ✓ | ✓ | | |
| | | Infotainment control module | ✓ | ✓ | | |
| | | Rear differential control module | ✓ | ✓ | | |

Models equipped with OBD-II Connector, SELECT BY SYSTEM: (for unknown models / versions only)

| SYSTEM | READ FAULT CODE | CLEAR FAULT CODE | DATA STREAM | CODING |
|--------|-----------------|------------------|-------------|--------|
| ENGINE | ✓ | ✓ | | |
| AT | ✓ | ✓ | | |
| ABS | ✓ | ✓ | | |
| SRS | ✓ | ✓ | | |

The information contained herein is the exclusive property of Autoland Scientific® and shall not be distributed, reproduced, or disclosed in whole or in part without prior written permission of Autoland Scientific®. Autoland Scientific® reserve the right to make any change without notice. The trademark mentioned belong to the owners.